

SOCOMEC	MANUAL COS		LOAD BREAK	SWITCH FUSE COS	OLD COS
01-01-19	Sircover	COS W.ENCL	OPEN-EX	OPEN-EX	OPEN -EX
HSN CODES	8536	8536	8536	8536	8536
63A	4834	6944			
100A	6382	8851			
125A	9615	13146	4794	12202	9904
160A	10413	14415			10830
200A	12685	16645	6896	22312	13065
250A	18293	23145	8962	22516	18842
315A	19123	24220	9651	23257	19696
400A	28205	35412	13412	33348	29052
630A	32861	41031	16167	38920	34179
800A	54427	60891	21977		49221
1000A	83111	107884	36819		83111
1200A	110783	149165	50328		110783
1600A	130940	199039	67952		130940